

# FLASH PARCS Monthly - ParkWhiz App




FLASH PARCS supports a Bluetooth Low Energy (BLE) feature that allows frictionless access for registered monthly parkers. Each entry and exit kiosk are outfitted with a BLE beacon device. FLASH PARCS gives monthly parkers the option to open the gate when within Bluetooth range of the kiosk using the ParkWhiz app.

## Note:

If you are not able to activate the ParkWhiz app... contact the Parking Team at:  
[parking@easton-pa.gov](mailto:parking@easton-pa.gov)

## INITIAL APP SET UP INSTRUCTIONS

1. Download the ParkWhiz app from the App Store or Google Play Store, once downloaded open the application.
2. The initial app download will require the "Let's Get Started" walk-through steps.
  - Allow "ParkWhiz" to use your location? Location services is not required to use the BLE function.
  - Turn on app Notifications. Enabled Notifications is not required to use the BLE function.



## ACTIVATE MONTHLY PARKING ACCESS

3. Tap on the **More** icon (with three horizontal bars) in the bottom right.
4. Tap **Activate Monthly Parking**.
5. Tap **Get Monthly Parking**.

**MORE**

1

HELP

SCAN TICKET TO PAY IN APP

ACTIVATE MONTHLY PARKING

Email Us

Legal

QR Code Verifier

Terms

Privacy

Version 9.1.1 (17546)  
© 2022 ParkWhiz, Inc.

HOME MY PARKING ACCOUNT MORE

**ACTIVATE MONTHLY PARKING**

2

ACTIVATE MONTHLY PARKING

Welcome

Select monthly parkers can enter and exit locations with QR code or Bluetooth. Click to see if your parking qualifies.


GET MONTHLY PARKING

We'll send a code to verify your phone number.

Need help?  
Visit our help center

HOME MY PARKING ACCOUNT MORE

8. A popup text message screen will appear.
9. Send the automatically generated code composed in the text message.
10. The system will respond via text message confirming the device has been registered and the app will confirm with a **Success** screen.
11. A phone setting popup message will ask for permission to use Bluetooth. Tap **OK** to allow the app to use the mobile device's Bluetooth.



**Note:**

Bluetooth **must** be enabled on the device to use the BLE access credential option.

# USING THE PARKWHIZ APP

The vehicle should be positioned within arms-length of the kiosk.

1. Open the ParkWhiz app on the mobile device.
2. From the Home tab, use the **Slide to Open Gate** feature to open the gate.
3. The QR code is another access option. The QR code can also be scanned on the kiosk's laser barcode reader to vend the gate.

